

Installation Instructions – Hurricane Turbo 998 Intake Adaptor

- 1) Remove the stock plastic turbo intake pipe from sled
- 2) Measure $1\frac{5}{8}$ " from the BOV as indicated in the picture



- 3) Sand the casting imperfections off the pipe from the new edge to about the nipple. This should allow a tight fit to work the Hurricane Turbo 998 Intake Adaptor to index it for proper clearance to the steering shaft and alignment with the turbo inlet



- 4) Mark the alignment so that you can remove the adaptor and apply any kind of plastic glue
- 5) Re-install the adaptor and align the rotation
- 6) Install back onto the sled and clamp the supplied silicone coupler to the turbo and the adaptor