

Instructions

- Step 1:** Place inlet tube over top the template.
Mark and cut inlet of indicated mark.
- Step 2:** Clean surface between cut mark and BOV inlet tube.
Sand area/scuff area to prepare hot glue to attach more effectively.
- Step 3:** Cover turbo inlet tube with 1" strip of hot glue.
Quickly press 3D printed inlet onto turbo inlet tube
-aligning white dot with mould seam.
Leave 1/8" gap between 3D piece and BOV inlet.

Template

